HEARSAY 1000 INSTRUCTIONS (Condensed)

To Load Demo Disk Type:

Load "Demo", 8, 1

Then press the RETURN key. After a few minutes the computer will speak an introduction phrase and show a menu with 6 items on the screen.

Press 1 for the demonstration of AQUA'S CIRCUS. After a few minutes the screen will show a clown and the computer will tell you what to do. Press F1 to return to the Main Menu.

Press 2 for a demonstration of THINK BANK. After a few minutes the screen will show a game board and the computer will tell you what to do. Hold down the CTRL Key and press R four times to return to the Main Menu.

Pressing 3 does not give a demonstration of RHYME AND REASON only an advertisement.

Press 4 for a demonstration of the INTELLIGENT TALKING TERMINAL. After a few minutes, the screen will ask you to train a few words. Then it will move on to the demo. You must complete the demo before returning to the Main Menu.

Press 5 for a demonstration of ZORK I with the HEARSAY 1000 unit. After a few minutes, the screen will ask you to train a few words. It will then move on to the demo. You must complete the demo before returning to the Main Menu.

Pressing 6 will bring you to a second menu where you can hear the different ways the HEARSAY unit can talk. Press 4 to return to the Main Menu.

To use the HEARSAY 1000 with existing software:

1. Screen Echo (Speech Synthesis)

    A. Press the RESTORE Key. The computer will say "HEARSAY 1000."

    B. Press the S Key. The computer will say "SCREEN MODE".

C. Press the F7 Key. The computer will say "SCREEN ECHO IS NOW ON".

D. Press RETURN. Load a program as you normally would and any text printed to the screen will be spoken.

2. Recognition

A. Press the RESTORE Key. The computer will say "HEARSAY 1000".

B. Press the T Key. The computer will say "YOU HAVE 0 WORDS TRAINED, ENTER NUMBER TO TRAIN." Enter 1 and press RETURN.

C. Press the SPACE BAR and say the word you want trained.

D. Repeat C.

E. Type the keys that you want the HEARSAY to send to the computer each time it hears that word.

F. Press RUN/STOP.

G. Repeat steps B through E for each word.

NOTE: With one word trained the computer will say "You have 1 word trained." Here you would enter number 2, return and so on for each new word trained (i.e. if 3 words were trained enter 4, return, if 6 words were trained enter 7, return).

H. Press R. The computer will say "RECOGNITION IS NOW ON".

I. Press M. The computer will say "PRESS SPACE BAR TO TALK".

J. Press RETURN. Now whenever you press the space bar and say a word you've trained, the keys entered earlier for that word will be sent to the computer as though you've typed them.

You can activate screen echo or recognition before or after a program is run. But for best results, activate them before the program is run.